Document No. 129-404 November 13, 2008

# OpenAir™ GCA Spring Return Rotary Electronic Damper Actuator




Figure 1. Parts of the GCA Actuator.

- a. Actuator
- b. Self-centering shaft adapter
- c. Position indicator
- d. Shaft adapter locking clip
- e. Position indicator adapter
- f. Mounting bracket
- g. Mounting screws
- h. 3 mm hex wrench
- i. Conduit adapter 1/2-inch (provided with GCA22x only)
- i. 500 ohm resistor (GCA15x.xx only)

## **Product Description**

Describes the steps for direct-coupled mounting of the OpenAir GCA spring return electronic damper actuators.

### **Product Numbers**

**GCAx** 

**Warning/Caution Notations** 

WARNING:	A	Personal injury or loss of life may occur if you do not follow a procedure as specified.
CAUTION:	A	Equipment damage or loss of data may occur if you do not follow a procedure as specified.

### **Required Tools**

- 10 mm (13/32-inch) open-end wrench
- Drill
- 4 mm (5/32-in) drill bit
- 3 mm hex wrench (provided)
- Phillips screwdriver
- Small flat-blade screwdriver
- Marker or pencil

### **Expected Installation Time**

30 minutes



### WARNING:

Do not open actuator.



#### **CAUTION:**

Do not turn the 3 mm hex key against the direction of the arrow.

## **Mounting Positions**




Figure 2. Acceptable NEMA 2-Positions.




Figure 3. Only Acceptable Position for NEMA Type 3R Rating Using ASK75.1U Weather Shield.

The GCA actuator is UL listed to meet NEMA Type 3R requirements (a degree of protection against rain, sleet, and damage from external ice formation) when installed with the Weather Shield (product number ASK75.1U) and outdoor-rated conduit fittings. Actuator must be in the vertical position.


### **Prerequisites**

**NOTE:** Actuator is shipped from the factory with 5° preload. When power is applied to the actuator, the preload is released. To manually release the preload, insert the 3 mm hex key in the override opening and turn the key in the direction of the arrow. See *Manual Override*.

Item Number: 129-404 Rev. DA

## Installation

Table 1. Actuator Positioning and Damper Control.






Figure 4. Shaft Length and Proper Shaft Adapter Location.




Figure 5. Close the Damper.




Figure 7. Fasten the Mounting Bracket.




Figure 6. Place the Actuator on the Shaft.




Figure 8. Fasten the Shaft Adapter to the Damper Shaft.

### **Manual Override**




Figure 9. Manual Override.

# To use manual override or set preload, do the following: (Figure 9)

- Insert the 3 mm hex key in the override opening, (Step 1).
- 2. Turn the key in the direction of the arrow until you reach the desired degree of opening, (Step 2).
- 3. Hold the key in place, (Step 3).
- Insert a small flat-blade screwdriver into the gear train lock pin. Turn the screwdriver in the same direction as the arrow until you hear a click or meet slight resistance, (Step 4).



### **CAUTION:**

When engaging the gear train lock pin, cautiously turn only about 5 degrees until you hear a click or meet slight resistance. Turning too far will strip the lock pin.

5. Remove the key or keep it in place, (Step 5).

### To release manual override or preload

- Insert the 3 mm hex key in the override opening, (Step 6).
- 2. Turn the key only a short distance in the direction of the arrow, (Step 7).
- 3. Remove the key, (Step 8).

The actuator will return to "0" (fail-safe) position.

**NOTE:** Applying power and sending a control signal will release manual override.

## **Mechanical Range Adjustment**




Figure 10. The Angular Rotation is Adjustable Between 0° and 90° at 5 Degree Intervals.

Make sure the actuator is in the "0" (fail-safe) position when making this adjustment. If making the adjustment before the actuator is in service, take into account the factory set 5° preload. To release the preload, see *To Release Manual Override or Preload* section.

### Other settings

For adjustment of auxiliary switches and span/offset options, see the individual Technical Instructions listed under *References* in the following table:

References	Document Number
EA GCA-1	155-173P25
OpenAir <sup>™</sup> Spring Return Rotary Electric	
Damper Actuator Modulating Control	
EA GCA-2	155-174P25
OpenAir™ Spring Return Rotary Electric	
Damper Actuator 24 Vac/dc and 120 Vac	
2-Position Control	
EA GCA-3	155-175P25
OpenAir™ Spring Return Rotary Electric	
Damper Actuator 24 Vac/dc 3-Position	
Control	
OpenAir Weather Shield Kits	129-261
Installation Instructions	

### Wiring

- All wiring must conform to NEC and local codes and regulations.
- Use earth ground isolating step-down Class 2 transformers. Do not use autotransformers.

### NOTE:

The maximum rating for a Class 2 step-down transformer is 100 VA. Determine the supply transformer rating by summing the VA ratings of all actuators and all other components used. It is recommended that not more than 80% of the transformer VA be utilized. The GCA actuator consumes 8 VA or 9 VA.



### **CAUTION:**

Mixed switch operation to the switching outputs of both auxiliary switches (A and B) is not permitted.

Either AC line voltage from the same phase must be applied to all six outputs of the dual auxiliary switches, or UL-Class 2 voltage must be applied to all six outputs.


**NOTE:** With Plenum cables, only UL-Class 2 voltage is permitted.

Wiring, continued


rring, continuou						
Actuator	Operating Voltage	Power Consumption				
Modulating Control						
GCA16x	24 Vac	9 VA				
GCA15x	24 Vac/dc	9 VA/7W				
2-Position and 3-Position Control						
GCA12x, GCA13x	24 Vac/dc	8 VA/6W				
GCA22x	120 Vac	9 VA				

## **Wiring Diagrams**


Modulating 0 to 10 Vdc Control, 24 Vac: GCA16x Modulating 2 to 10 Vdc Control, 24 Vac/dc: GCA15x



2-position Control, 24 Vac/dc: GCA12x



3-position Control, 24 Vac/dc: GCA13x



2-position Control, 120 Vac: GCA22x





Table 2. Wire Designations.

r	rable 2. Wire Designations.								
Standard Symbol	Function	Terminal	Color						
	Function	Connection	Standard	Plenum					
1	Supply (SP)	G	Red	Red					
2	Neutral (SN)	G0	Black	Black					
3	Line	L	Black	Black					
4	Neutral	N	White	White					
6	Control signal clockwise	Y1	Violet	Violet					
7	Control signal counterclockwise (GCA16x)	Y2	Orange	Orange					
8	Input Signal 0 to 10 Vdc (GCA16x) 2 to 10 Vdc (GCA15x)	Y	Gray	Gray					
9	Position Output 0 to 10 Vdc (GCA16x) 2 to 10 Vdc (GCA15x)	U	Pink	Pink					
S1	Switch A Common	Q11	Gray/ red	Gray/ red					
S2	Switch A N.C.	Q12	Gray/ blue	Gray/ blue					
S3	Switch A N.O.	Q14	Gray/ pink	Gray/ pink					
S4	Switch B Common	Q21	Black/ red	Black/ red					
S5	Switch B N.C.	Q22	Black/ blue	Black/ blue					
S6	Switch B N.O.	Q24	Black/ pink	Black/ pink					
P1	Feedback Potentiometer 0 to 100% P1 - P2	а	White/ red	Black					
P2	Feedback Potentiometer Common	b	White/ blue	Black					
P3	Feedback Potentiometer 100 to 0% P3 - P2	С	White/ pink	Black					

Special Application: **Modulating 4 to 20 mA Control** with GCA15x and external 500 ohm resistor



### **Dimensions**




Figure 11. Dimensions of the ASK75.1U Weather Shield in Inches (Millimeters).




Figure 12. Dimensions of the GCA OpenAir Actuator and Mounting Bracket in Inches (Millimeters).

Information in this publication is based on current specifications. The company reserves the right to make changes in specifications and models as design improvements are introduced. OpenAir is a registered trademark of Siemens Building Technologies, Inc. Product or company names mentioned herein may be the trademarks of their respective owners. © 2008 Siemens Building Technologies, Inc.