

INSTALLATION INSTRUCTIONS
NATURAL to L.P. GAS CONVERSION KIT
 For 30,000 to 120,000 BTU/HR
 Tubular Unit Heaters with **Direct Spark Ignition**



Unit Heat Exchanger Material	Input BTU/HR	Conversion Kit No.	Orifice Size L.P.	Orifice Part No.	Convertible Valve
Aluminized Steel	30,000	11CKNTPDS030-52	#52	11512-08532-011	36G22-220
Aluminized Steel	45,000	11CKNTPDS045-48	#48	11512-08532-012	36G22-220
Aluminized Steel	60,000	11CKNTPDS060-43	#43	11512-08532-008	36G22-220
Aluminized Steel	75,000	11CKNTPDS075-40	#40	11512-08532-023	36G22-220
Aluminized Steel	90,000	11CKNTPDS090-36	#36	11512-08532-009	36G22-220
Aluminized Steel	105,000	11CKNTPDS105-32	#32	11512-08532-021	36G22-220
Aluminized Steel	120,000	11CKNTPDS1203.1	3.1MM	11512-08532-022	36G22-220
409 Stainless Steel	30,000	11SKNTPDS030-53	#53	11512-08532-013	36G22-220
409 Stainless Steel	45,000	11SKNTPDS045-49	#49	11512-08532-025	36G22-220
409 Stainless Steel	60,000	11SKNTPDS060-44	#44	11512-08532-026	36G22-220
409 Stainless Steel	75,000	11SKNTPDS075-41	#41	11512-08532-027	36G22-220
409 Stainless Steel	90,000	11SKNTPDS090-37	#37	11512-08532-019	36G22-220
409 Stainless Steel	105,000	11SKNTPDS105-33	#33	11512-08532-028	36G22-220
409 Stainless Steel	120,000	11SKNTPDS1203.0	3.0MM	11512-08532-029	36G22-220

Kit Contents

Main Burner Orifice (1)
 See Table for Part Number

“Notice of Conversion”
 Label
 11J17-02754

White-Rodgers Gas Valve
 Conversion Kit
 W-R# 92-0659
 11J29-02775-001

Conversion Plate
 11J17-02755

▲ WARNING This conversion kit shall be installed by a qualified service agency in accordance with the manufacturer's instructions and all applicable codes and requirements of the authority having jurisdiction. If the information in these instructions is not followed exactly, a fire, explosion or production of carbon monoxide may result causing property damage, personal injury or loss of life. The qualified service agency performing this work assumes responsibility for the proper conversion of this appliance with this kit.

AVERTISSEMENT Cette trousse de conversion ne doit être installée que par le représentant d'un organisme qualifié et conformément aux instructions du fabricant et à tous les codes et exigences pertinentes de l'autorité compétente. Quiconque ne respecte pas à la lettre les instructions du présent guide risque de provoquer un incendie, une explosion ou des fuites de monoxyde de carbone entraînant des dommages matériels, des lésions corporelles ou la perte de vies humaines. L'organisme qualifié qui effectue les travaux est responsable de la conversion correcte de cet appareil à l'aide de cette trousse.

High Altitude Deration – United States

Altitude		Manifold Pressure		BTU Output ¹
		Liquid Propane ²		
Feet	Meters	Inches W.C.	Pa	Percentage
0-2,000	0-610	10.0	2,491	100%
2,001-3,000	611-915	9.2	2,292	96%
3,001-4,000	916-1,220	8.4	2,092	92%
4,001-5,000	1,221-1,525	7.7	1,918	88%
5,001-6,000	1,526-1,830	7.0	1,744	84%
6,001-7,000	1,831-2,135	6.4	1,594	80%
7,001-8,000	2,136-2,440	5.7	1,420	76%
8,001-9,000	2,441-2,745	5.1	1,270	72%
9,001-10,000	2,746-3,045	4.6	1,145	68%

Notes: 1. Deration based on ANSI Z223.1 (NFPA 54).

2. Table based on heating value of 2,500 BTU/Cu. ft. at sea level.

3. Consult local utility for actual heating value

High Altitude Deration – Canada

Altitude		Manifold Pressure		BTU Output ¹
		Liquid Propane ²		
Feet	Meters	Inches W.C.	Pa	Percentage
0-2,000	0-610	10.0	2,491	100%
2,001-3,000	611-915	9.2	2,292	96%
3,001-4,000	916-1,220	8.4	2,092	92%
4,001-4,500	1,221-1,371	7.9	1,968	90%

Notes: 1. Deration based on CGA 2.17-M91

2. Table based on heating value of 2,500 BTU/Cu. ft. at sea level.

3. Consult local utility for actual heating value

**READ ALL INSTRUCTIONS COMPLETELY
 BEFORE BEGINNING ANY WORK!**



1. All work must be performed by a fully qualified, experienced, and trained service technician. It is the responsibility of the installer to follow all instructions. Failure to follow these instructions could result in serious injury or property damage.
2. The qualified agency performing the work assumes responsibility for the conversion.
3. **▲ CAUTION** The gas supply shall be shut off prior to disconnecting the electrical power, before proceeding with the conversion.
4. Wear safety glasses.
5. Wear gloves when handling the burner.
6. Be sure of ladder placement. Do not allow people to stand below or around the area where the work is being performed.
7. Do not lean ladders or equipment against the heater at any time during the conversion.

REPLACING THE ORIFICES (See Figure 1)

1. Remove the four hex head screws holding the access panel and remove the panel.
2. Use the proper size wrench or socket to remove the burner orifice. Remove the natural gas orifice and keep it separated from the L.P. orifice at all times.
3. **NOTICE: Install L.P. gas orifice in manifold, ensuring that the number stamped on the orifice matches the size listed on page one for the appliance being converted.** The orifice must be installed finger tight first to avoid cross threading and the possibility of leaking. Tighten securely with wrench or socket. Do not over tighten.

CONVERSION OF THE GAS VALVE

1. Follow all instructions provided with the valve conversion kit. Be sure valve conversion kit is for the valve on the appliance. If the instructions are lost or not in the kit **STOP**. Call the Customer Service Department and the instructions will be faxed to you.

OPERATION

1. A water-filled U-tube manometer must be used to measure gas pressures. The gauge type is not reliable and may give false readings.
2. Gas inlet pressure must be between 11.0 and 14.0 inches water column (2.7-3.5 kPa). Turn off the gas supply to the heater, connect the manometer to the pressure tap on the inlet side of the gas valve, turn on the gas and observe the pressure with the heater not firing and then firing. If the pressure is not within the specified range under both conditions, contact the gas supplier.
3. The manifold pressure must be adjusted to 10.0 inches water column (2.5 kPa). This manifold pressure applied to the main burner orifice assures that the input rating is correct for altitudes up to 2000 feet (610 m). For altitudes above 2000 feet (610 m), see (4) below. This is very critical as overfiring or underfiring can cause problems. Move the manual control on the gas valve to the "Off" position, connect the manometer to the pressure tap on the outlet side of the gas valve, turn the control on, fire the unit and adjust the pressure if necessary.

To adjust the pressure, remove the cap from the pressure regulator on the gas valve, turn the regulator screw clockwise to increase pressure or counter clockwise to decrease pressure, then replace the cap.

4. For altitudes above 2000 feet (610 m), heater must be derated 4% for each 1000 feet (305 m) above sea level. Adjust manifold pressure according to the L.P. Gas High Altitude Manifold Pressure Chart on page one.
5. After manometers have been removed and pressure tap plugs have been reinstalled, fire the heater and check all joints for leaks using a soap solution. **Never use an open flame to check for gas leaks.**
6. Allow the heater to operate for at least 5 minutes, then observe the main burner flame. A hard blue flame extending into the tube is normal. Slight yellow tipping is acceptable. There is no air adjustment on burner.
7. After the heater is operating properly, cycle the system using the thermostat to check out the normal operating sequence of the ignition system. The normal sequence is as follows:
 - Thermostat calls for heat, draft inducer fan starts.
 - After a purge period, main gas valve and ignitor are energized.
 - Main flame ignites.
 - Sensing circuit senses flame, turns ignitor off.
 When thermostat is satisfied, the gas valve is de-energized, extinguishing the main burner flame.

CONVERSION PLATE

1. Apply conversion plate and label to heater jacket panel. The conversion plate must be installed as closely as possible to the existing heater rating plate.
2. Replace access panel.

▲ WARNING Gas Tightness Of The Safety Shut-Off Valves Must Be Checked On At Least An Annual Basis!

To check gas tightness of the safety shut-off valves, turn off the manual valve upstream of the appliance combination control. Remove the 1/8 inch pipe plug on the inlet side of the combination control and connect a manometer to that tapping. Turn the manual valve on to apply pressure to the combination control. Note the pressure reading on the manometer, then turn the valve off. A loss of pressure indicates a leak. If a leak is detected, use a soap solution to check all threaded connections. If no leak is found, the combination control is faulty and must be replaced before putting appliance back in service.

Figure 1

