

SSIC2-0226

W30-WG1714

SPACEPAK®

SPACEPAK SYSTEM INTERFACE CONTROL

INSTALLATION, OPERATION & MAINTENANCE MANUAL



IN UNITED STATES: 260 NORTH ELM ST. WESTFIELD, MA 01085 800-465-8558

IN CANADA: 7555 TRANMERE DRIVE, MISSISSAUGA, ONTARIO, L5S 1LR (905) 670-5888

Contents

- Section 1: Introduction 4
 - Unit Description..... 4
 - Operation 4
 - Buffer Tank 4
 - Buffer Tank Operation..... 4
 - Buffer Bypass..... 5
 - Buffer Override..... 5
 - ThinWall Control 5
 - Modbus Connected Heatpumps..... 6
- Section 2: Installation 7
 - Mounting 7
 - Wiring..... 7
 - Outdoor Air Temperature Sensor 7
 - Buffer Tank Temperature Sensor..... 7
 - SSIC Terminal Blocks 8
 - Buffer Tank Bypass..... 10
 - Four Pipe Buffer Tank 11
- Section 3: SSIC Menu Tree 12
- Section 4: Operation 17
 - Control Logic 17
 - Main Screen – No Buffer Tank 18
 - Main Screen – Buffer Tank..... 18
 - Main Screen – Modbus Heatpumps 18
 - Settings Menu 19
 - Master Zone 19
 - Boiler/Heatpump OP..... 20
 - Heatpump Only Mode..... 20
 - Boiler Only Mode 20
 - Boiler Help..... 20
 - Outdoor Air (OA) Switch Over 21
 - Separate Boiler..... 21
 - Heatpump RV 21
 - Buffer Tank..... 21
 - OA Curve..... 23
 - Tank Setpoints 23
 - ThinWall 25
 - Modbus Heatpumps 26
 - Modbus Staging 27
 - Runtimes 27
 - Timers 28
 - System Settings 28

Temperature Units.....	28
Restore Defaults.....	28
Load Firmware	29
About.....	31
Section 5: Variable Descriptions and Defaults.....	32

Outside Air Temperature		System Mode
°F	°C	
< 50°F	< 10°C	Heating
> 65°F	> 18.3°C	Cooling
50°F > OAT > 65°F	10°C > OAT > 18.3°C	Idle

Table 2: Temperatures shown are default values and are adjustable.

If the system mode is IDLE, any calls from zones are serviced on a first come first served basis.

When in either BUFFER HEATING or BUFFER COOLING mode, the control will continue to call until the water temperature in the tank reaches the setpoint for that mode. Once the temperature in the buffer tank has reached its setpoint, the buffer mode switches to SATISFIED and the temperature is allowed to change by an amount determined by the DIFF (Differential) settings (default 2° for HI and 6° for LO for heating, 6° for HI and 2° for LO for cooling), after which point the heating/cooling will again work to satisfy the buffer demand.

There are 2 potential sources for heating depending on how each system is set up (boiler or heatpump) so there are 2 different set points for heating (160°F and 120°F [71.1°C and 48.9°C]). Setpoints can be adjusted in the buffer tank setpoints menu as shown later in this document. If the buffer tank option is used an OAT and buffer tank sensor are both required regardless of operating mode.

System Mode	Buffer Tank Temperature		Buffer Mode
	°F	°C	
Heating	<160°F	<71.1°C	Heating
	>160°F	>71.1°C	Satisfied
Cooling	>48°F	>8.9°C	Cooling
	<48°F	<8.9°C	Satisfied

Table 3: Temperatures shown are default boiler values and are adjustable.

Buffer Bypass

The buffer tank may be bypassed with the installation of bypass valves (see example piping diagrams later in the document). If conditions allow the buffer tank demand to remain IDLE there is no need to maintain a temperature in the tank. Calls would be serviced directly from the heatpump or boiler instead, saving energy by not having to heat up the water in the tank.

Buffer Override

Buffer override allows the buffer tank demand to be overridden if the right conditions are met. If the buffer tank's temperature demand has been satisfied and there is a call for the opposite mode from the system and there are no other zone calls, the buffer tank can be overridden so the zone may be satisfied directly from the sources. For the buffer override feature to work the system must have bypass valves installed (shown in plumbing diagram) and the Buffer Bypass and Buffer Override must be enabled on the controller.

Note: If bypass valves are not installed and enabled the system will never service calls from zones that oppose the buffer tank's calls even if the buffer tank is satisfied. For example, if the OAT is below 50°F(10°C) (default) any cool calls from zones will not be serviced.

Dual Buffer Tank

Version 1.8 and later of the SSIC firmware offers support for dual buffer tank control, with supply from heatpumps controlled by a valve. Bypass and override features are not available when using the dual buffer tank feature. Control of each buffer tank is the same as normal, each having their own set of setpoints accessible in the Buffer Tank menu. Tank 1 always has priority and will override Tank 2's demands.

ThinWall Control

If a Spacepak ThinWall unit is installed in a zone, the control needs to be configured to accommodate it. The ThinWall fan coil unit has one control output and uses the OAT to predict if the zone needs heating or cooling. Each zone with a ThinWall unit must have ThinWall control enabled from the ThinWall menu on the SSIC to properly set the heating or cooling mode as necessary. In addition to an enable for each zone, the user can set the OAT switchover, hysteresis, and a control timeout for systems with a mix of ThinWall and non-ThinWall units.

ThinWall inputs must be connected to the W terminal of the appropriate zone to operate. The control will not recognize anything connected to Y if ThinWall is enabled for that zone.

Modbus Connected Heatpumps

Firmware version V1.8 and later offer the ability to communicate with up to 20 Modbus connected heatpump units via RS-485. Supported heatpump units include HP0275, ILAHP, SIM036, SIM060, CC32-18/-40/-60, and HT454B-04/-60. Once set up, the SSIC will automatically handle heating and cooling with the added features of advanced communication and staging. Staging of heatpump units is based on runtime, which is calculated and stored in the SSIC. This feature is only available when using a buffer tank. See heatpump unit documentation for wiring of communication lines.


Section 2: Installation

Mounting

SSIC Mount the control box in a dry indoor location that has easy wiring access from the air handler(s), and the outside heatpump.

There are three hole locations for mounting the SSIC (see below).

1. Use a #8 wood screw and corresponding wall anchor to mount the SSIC. Secure wood screw into anchor leaving 3/16" (5mm) between screw head and the wall. Hook the unit and slide into place.
2. Remove lower front panel. Use two #5 wood screws in the bottom hole locations to secure the unit to the wall.



Wiring



Electrical shock hazard - Disconnect all electrical power before wiring the unit.

1. Remove the lower access panel to gain access to the wire terminals.
2. Pass the wires from the Air Handlers, Pump, Heatpump, etc. through the grommets at the bottom of the unit and plug into their corresponding connector (see below or for more detailed information see the wire diagram on page 6)
3. When all wiring between the air handlers, pumps, and heatpumps is completed, connect the power.
4. When connecting 115V, connect the line (hot) wire to L; connect the neutral wire to N, and connect the ground wire (bare copper or green) to G.

Outdoor Air Temperature Sensor

- Avoid areas subject to excessive vibration, electrical noise, direct sunlight, or the effects of radiant heat.
- Keep electrical wiring as short as possible to minimize temperature error.

Buffer Tank Temperature Sensor

1. Coat sensing bulb liberally with heat transfer paste. (SpacePak part number 45Y09-WG1719-01. Supplied in box)
2. Insert sensor into well of the buffer tank.
3. Slide plastic locknut over the lead and hand tighten only onto the threads of the bulb well.
4. Route lead back to the heatpump and connect to terminals X+Y (as indicated in the heatpump IOM).

Modbus Wiring

1. Shielded communication cables with at least 3 conducting wires should be used for optimal communication. Shielding should be attached to earth ground only.
2. When using Modbus communication, connect the 120 ohm Terminating Resistor, SpacePak part number 45Y08-WG1719-01, supplied in box, between the RS485 A and B terminals of the last, or only, heat pump in the circuit.
3. For control boards marked Rev. 1.3 or earlier, place an additional 120 ohm resistor between terminals A2 & B2 of the COM2 plug. For those marked 1.4 or later, move the DIP switch marked HP to the ON position.

SSIC Terminal Blocks




Figure 1: Wiring Connectors

OA	Outdoor Air Temperature Sensor (included)	ZONE X	Connection from Zone X (1-5) Air Handler
WATER	Buffer Tank 1 Temperature Sensor (included)	XW	24VAC Heating Signal from Air Handler
RETURN	Return Water Temperature (For future consideration, not currently used)	XY	24VAC Cooling Signal from Air Handler
SENSE	Buffer Tank 2 Temperature Sensor	XC	Ground from Air Handler
R	24VAC	HEATNET	RS485 communication to Heat Net (for future consideration, not currently used)
RELAY	Relay contact to enable the bypass valves or other dedicated load.	HEATPUMP	RS485 communication to Solstice Heat Pump(s)
PUMP	Enable signal for a Secondary circulator (buffer tank to emitters) in the system. Do not use for the Primary (heat pump to buffer tank) circulator.	SSIC	General RS485 communication (for future consideration, not currently used)
BOILER	Relay contact to enable the Boiler.	C	24VAC Common
HEATPUMP	Relay contact to enable the Heat Pump.		
RV	Relay contact to energize the Reversing Valve.		

SPACEPAK SYSTEM INTERFACE CONTROL FIELD WIRING




Figure 2: Example system wiring diagram.


Buffer Tank Bypass

Buffer Tank Bypass is a function available within the SSIC that allows a hydronic system to store thermal energy in the form of heated or chilled water. The Heat Pump simultaneously reverses cycle to satisfy a temporary demand that is the opposite of the prevailing operating mode (i.e., a cooling call when the system is operating in heating mode, or a heating call when the system is operating in cooling mode)


Four Pipe Buffer Tank

This is the most common buffer tank installation. The primary loop is routed through one side of the buffer tank, the secondary loop through the other. When the Bypass feature is engaged, each of the four three-way valves transfers, isolating the buffer tank and creating two runaround paths linking the Heat Pump directly to the emitters.

BUFFER TANK BYPASS PIPING, FOUR PIPE CONFIGURATION





CHARGING




BYPASS


Figure 3: Four Pipe Buffer Tank





Tank setpoints
when OA Curve is
enabled





Section 4: Operation

Control Logic (Firmware V1.94)


The following sections outline how the SSIC can be configured using the menus that appear on its display. Menus are navigated using the UP, DOWN, BACK, and SELECT keys on the keypad.

The user navigates to the setting they want to change by using the UP and DOWN keys. Pressing SELECT will move the cursor in front of the selectable options. Pressing the UP and DOWN keys will change the state from disabled to enabled or vice versa. Pressing the SELECT key saves the setting and pressing BACK will revert to its original setting. While navigating the main screen pressing BACK at any time will return to page 1 where applicable.

In an ongoing effort to provide the customer with the best performance possible, SpacePak may make minor upgrades to the SSIC operating software at any time.

These changes may provide additional functionality to the device, but will never remove any features, and are often transparent to the user. Therefore, this document may not require updating with every change. It is current at the time of publishing but may not reflect the most recent software version.

Your software version can be seen in the Startup Screen immediately after powering up the device. This will remain visible for a few seconds before proceeding to the Home Screen. Alternately, for units with v1.8 or later, scroll down to the bottom of the screen menu and the ABOUT screen. The installed software version is visible here.



If you would like to see if there are any notes related specifically to your device’s software version or learn if there are later versions that you may download and install, you can view the QR code below and follow the link to the list of software revisions, effective dates, and description of the change. You can also select the option to download the software, which can be loaded onto a portable USB drive and installed in the SSIC. Instructions are provided in the **Load Firmware** section of this manual.

Note: Upgrading the firmware can be done at your discretion. It is not mandatory, and your choice to do so or not will not affect your service and support, or the warranty coverage on the SSIC.



SCAN QR CODE

→	O	A	F	l	o	o	r	:	E	n	a	b	l	e	d			
	F	l	o	o	r	T	e	m	p	:					2	0	°	F

Figure 16: OA Floor settings.

Required Sensors: Buffer, OA

Outdoor Air (OA) Switch Over

OA switchover will change the heat source between the heatpump and boiler depending on the outside air temperature. If the OAT is below or equal to the setpoint (40°F [4.4°C] default) the boiler will provide the hot water, above the setpoint the heatpump will provide the heat.

Required Sensors: OA and buffer tank if buffer tank is enabled, OA otherwise.

S	e	t	O	A	S	w	i	t	c	h	o	v	e	r				
T	e	m	p	e	r	a	t	u	r	e								

Figure 17: OA Switchover Settings.

Separate Boiler

If the system has a boiler feeding directly into the serviced loop and bypassing a buffer tank the Separate Boiler option can be enabled. The system will maintain a buffer tank as explained in the buffer tank sections of this document using the heatpump as the source until the OAT drops to or below the setpoint (40°F [4.4°C] default). Once below that SP the boiler services any calls for heat, while the heatpump would still service any calls for cool. Zones are serviced on a first come first served basis. Buffer override and buffer bypass are disabled until the OAT rises above the SP. When the OAT is below the setpoint and there is a call for heat, the system pump is disabled regardless of the pump setting.

S	e	t	O	A	S	w	i	t	c	h	o	v	e	r				
T	e	m	p	e	r	a	t	u	r	e								

Figure 18: Separate Boiler Settings.

Required Sensors: OA and buffer tank if buffer tank is enabled, OA otherwise.

Heatpump RV

The user can change the heatpump’s reversing valve to be energized in either Cooling (O) or Heating (B) operation depending on system requirements.

Buffer Tank

All buffer tank options can be found here, including enables, disables, and temperature settings.

When the buffer tank option is disabled, no other menu options appear on the buffer tank menu.

→	T	a	n	k		1	:	D	i	s	a	b	l	e	d			

Figure 19: Buffer Tank 1 disabled.

Tank 1 and Tank 2 have 4 run modes:

→	B	u	f	f	e	r	:	E	n	a	b	l	e	d		
	B	y	p	a	s	s	:	E	n	a	b	l	e	d		
	O	v	e	r	r	i	d	e	:	E	n	a	b	l	e	d
	O	A	C	u	r	v	e	:	E	n	a	b	l	e	d	

Figure 25: All buffer tank options enabled.

Using a buffer tank always requires the use of a buffer tank sensor and OA sensor regardless of Boiler/Heatpump OP settings.

OA Curve

An Outdoor Reset curve is available for use with a Buffer Tank. This feature will change the buffer tank setpoint depending on the OAT. It may only be enabled when the buffer tank option is enabled.

OA curve heating example: if the OAT < Heat OA Lo, the tank setpoint will be either Heat Tank B or C (depending upon op mode) Hi. If the OAT > Heat OA Hi, the tank setpoint will be Heat Tank Lo. If the OAT is between those setpoints, the tank setpoint will scale linearly between the Hi and Lo setpoints.




Figure 26: Example heat curve




Figure 27: Example cool curve

Tank Setpoints

Temperature setpoints for the buffer tank can be found on the second page of the buffer options. Pressing the UP or DOWN arrow off the page will scroll to the next page.

→	T	a	n	k	S	e	t	p	o	i	n	t	s		

Figure 28: Buffer option menu continued.

→	Z o n e 5 :	D i s a b l e d					
	T W	S e t p o i n t :				5 0 ° F	
	T W	+ / -				5 ° F	
	T W	T i m e r				1 5 m i n	

Figure 42: ThinWall settings page 2. Default values shown.

When the ThinWall unit’s internal thermostat sends a call to the SSIC, the SSIC checks the OAT. If the OAT is above the setpoint, the system will call for cool; below the setpoint, it will call for heat. Once the OAT reaches the setpoint +/- the hysteresis setpoint, the call will switch to the opposite type.

Example using default settings: OAT is 40°F (4.4°C) when the zone calls. Heat is provided. OAT rises to 55°F (12.8°C), system switches to cooling.

The timer is provided for installations that have 1 or more zones with a ThinWall unit and 1 or more standard fan control units. If all zones are idle and a TW zone calls first, the TW zone will set the system mode. If a standard zone calls for the opposite mode while the TW zone is actively calling, the timer will start. The TW mode will continue to be serviced until the timer expires. The system then switches over to service the standard zone. Normal operation resumes from this point.

The timer can be disabled by setting the value to 0 minutes. If all zones are TW zones, this setting can be ignored.

Modbus Heatpumps

Modbus Heatpump settings can be found here. Use this menu to set up address (1-20), unit type, and heat and cool setpoints if desired. The address must be set using each heatpump unit’s interface before adding to the SSIC. See heatpump documentation for more details on setting the address.

	M o d b u s	H P	S e t u p				
→	A d d r e s s :	1					
	M o d e l	T y p e :	S I M 0 6 0				
	S e t p o i n t s :	A u t o					

Figure 43: First page of the Modbus Heatpump Setup menu, SIM060 at address 1 shown as example.

Setpoints can be either be set automatically, set for all heatpumps at once, or adjusted for each heatpump individually. The automatic setting can be used in most cases and works in a similar fashion to outdoor reset; the further away the tank temperature is to its target, the higher the heatpump setpoints are.

→	T a n k	H i :				1 0 ° F	
	T a n k	L o :				0 ° F	
	H e a t	P u m p	H i :			1 0 ° F	
	H e a t	P u m p	L o :			0 ° F	

Figure 44: Auto setpoint default settings.

For example, with the default settings, if the tank temperature is more than 10°F (-12.2°C) away from its target temperature, the heatpump will be set at 10°F (-12.2°C) higher/lower than the tank’s target temperature and is scaled between setpoints if below the Tank Hi setpoint.

NOTE: Temperatures displaying on the SSIC may be rounded or truncated due to unit conversion between Modbus connected units and the SSIC.

Alternately, the temperatures can be set manually for either all units at once or for each individual unit.

	T y p e :	S I M 0 3 6				I D : 1	
→	H e a t	S P :				1 3 0 ° F	
	C o o l	S P :				4 6 ° F	
	S e t	A l l	U n i t	T e m p s			

Figure 45: Setting heat and cool setpoints on Unit 1 manually.

Choose the unit ID from the first page in the Modbus HP Setup menu (Figure 34), then set the setpoints as desired. To use those setpoints for every connected unit select Set All Unit Temps on line 4, then select Set all on the next page to confirm.




Figure 53: Restore defaults menu.




Figure 54: Restore defaults confirmation.

Load Firmware

This setting walks the user through the process of updating new firmware into the control via a USB drive. USB drives must contain a directory called “firmware” and have the .hex file in this directory. USB drives must be formatted as FAT32 for firmware loading to work. Contact Mestek support for a pre-configured drive, or format a clean USB drive if so desired.

1. With the control powered on, press SELECT and scroll down to the menu option “Load Firmware” as shown in the menu tree in Section 3.
2. The user will be prompted to insert their USB drive into the USB terminal.




Figure 55: Update firmware first screen.

3. Once the USB drive is in place and the user hits the SELECT key, a brief “PLEASE WAIT...” response will be displayed. After a brief wait, the user will be prompted to select the firmware .hex file they wish to load. Use the UP and DOWN keys to navigate to the file if there is more than one file, press the SELECT key to select the file, and the BACK key to abort.




Figure 56: Update firmware second screen.

If no USB drive is detected or it is not the correct format, the following will be displayed:




Figure 57: Update firmware no drive.

If no firmware is found or there is no “firmware” directory, the following will be displayed:




Figure 58: Update firmware no firmware.

- After selecting the file, the user may be asked to select the storage location. If prompted, select storage location 1. This screen is skipped when updating from version 1.2 or later.



- A loading screen will appear with a number that increases quickly, indicating the process of the file data transfer. After it is complete, a "SAVING FILE" message will appear.




Figure 59: Loading screen.

- The "UPDATE ON REBOOT" screen asks the user if they would like to commit to the firmware they just loaded. Pressing the UP or DOWN keys will cycle between the 'Yes' and 'No' options. If 'YES' is selected then the firmware will be loaded into flash and the control will reboot with the new firmware. If 'NO' is selected then the new firmware will not be loaded and the user will be returned to the menu screen. This screen is skipped when updating from version 1.2 or later.



Figure 60: Reboot option.

- A flash screen will appear with a loading bar indicating the progress of the flash process.



Figure 61: Flashing.

- After the flash process completes a message will appear indicating that the new firmware has been loaded. The control will then reboot itself with the new firmware. All the settings will return to their defaults.




Figure 62: Firmware loaded.

About

Shows firmware build version.

		S	S	I	C	F	I	R	M	W	A	R	E	:		
						v	1	.	9	2						
		P	r	e	s	A	n	y	B	u	t	t	o	n		
				T	o	E	x	i	t							

Figure 63: Firmware version.

Section 5: Variable Descriptions and Defaults

Section	Name	Description	Default Value	Max Value	Min Value
Boiler Help	Low Temp	Boiler will help the heatpump provide heat if the heatpump has not been able to raise the temperature above this value. When using Boiler Help and Outdoor Reset, be sure the Boiler Help Low Temp is below the Hot Tank Low value.	80°F	140°F	40°F
			26.7°C	60°C	4.4°C
	Time	Time limit for the boiler to start assisting the heatpump provide heat	2 min	100 min	0 min
	Boiler Help Shutoff	Boiler enable will turn off at this water/tank temperature depending on settings	110°F 43.3°C	140°F 60°C	40°F 4.4°C
	OA Floor	In Boiler Help mode boiler will turn on immediately if the OA is below this OA temperature	20°F -6.7°C	80°F 26.7°C	0°F -17.8°C
OA Switchover	Temp	Outside air temperature value where the system will switch the heat source	40°F 4.4°C	200°F 93.3°C	-10°F -23.3°C
OA Switchover – Separate Boiler	Temp	Outside air temperature value where the system will switch the heat source	40°F 4.4°C	200°F 93.3°C	-10°F -23.3°C
Buffer Tank 1	Buffer Enable	Enables/disables the buffer tank option	Enabled	N/A	N/A
	Bypass Enable	Enables/disables the bypass valves	Disabled	N/A	N/A
	Override Enable	Enables/disables the override function	Disabled	N/A	N/A
	Heat OA SP	Buffer tank starts calling for heat if the outside air is below this value	50°F 10°C	70°F 21.1°C	20°F -6.7°C
	Heat (B) SP	Water temperature target for the buffer tank when the boiler is the heat source	160°F 71.1°C	180°F 82.2°C	50°F 10°C
	Heat (HP) SP	Water temperature target for the buffer tank when the heatpump is the heat source	120°F 48.9°C	140°F 60°C	50°F 10°C
	Heat Diff Hi	Upper limit of the target heat band above setpoint	2°	20°	0°
	Heat Diff Lo	Lower limit of the target heat band below setpoint	5°	20°	0°
	Cool OA SP	Buffer tank starts calling for cool if the outside air is above this value	65°F 18.3°C	80°F 26.7°C	-20°F -28.9°C

	Cool Tank SP	Water temperature target for the buffer tank in cooling mode.	42°F 5.6°C	80°F 26.7°C	35°F 1.7°C
	Cool Diff Hi	Upper limit of the target heat band above setpoint	6°F -14.4°C	20°F -6.7°C	0°F -17.8°C
	Cool Diff Lo	Lower limit of the target heat band below setpoint	2°	20°	0°
Buffer Tank 2	Buffer Enable	Enables/disables the buffer tank option	Disabled	N/A	N/A
	Bypass Enable	Enables/disables the bypass valves	Disabled	N/A	N/A
	Override Enable	Enables/disables the override function	Disabled	N/A	N/A
	Heat OA SP	Buffer tank starts calling for heat if the outside air is below this value	30°F -1.1°C	70°F 21.1°C	20°F -6.7°C
	Heat (B) SP	Water temperature target for the buffer tank when the boiler is the heat source	160°F 71.1°C	180°F 82.2°C	50°F 10°C
	Heat (HP) SP	Water temperature target for the buffer tank when the heatpump is the heat source	120°F 48.9°C	140°F 60°C	50°F 10°C
	Heat Diff Hi	Upper limit of the target heat band above setpoint	2°	20°	0°
	Heat Diff Lo	Lower limit of the target heat band below setpoint	5°	20°	0°
	Cool OA SP	Buffer tank starts calling for cool if the outside air is above this value	50°F 10°C	80°F 26.7°C	-20°F -28.9°C
	Cool Tank SP	Water temperature target for the buffer tank in cooling mode.	42°F 5.6°C	70°F 21.1°C	35°F 1.7°
	Cool Diff Hi	Upper limit of the target heat band above setpoint	6°F -14.4°C	20°F -6.7°C	0°F -17.8°C
	Cool Diff Lo	Lower limit of the target heat band below setpoint	2°	20°	0°

Section	Name	Description	Default Value	Max Value	Min Value
DHW	Heat (B) SP	Water temperature target for the buffer tank when the boiler is the heat source	130°F 54.4°C	160°F 71.1°C	50°F 10°
	Heat (HP) SP	Water temperature target for the buffer tank when the heatpump is the heat source	130°F 54.4°	140°F 60°C	50°F 10°C
	Heat Diff Hi	Upper limit of the target heat band above setpoint	2°	20°	0°
	Heat Diff Lo	Lower limit of the target heat band below setpoint	5°	20°	0°
OA Curve	Heat OA Hi	High OA heat setpoint used for determining OA Curve	45°F 7.2°C	80°F 26.7°C	Heat OA Lo
	Heat OA Lo	Low OA heat setpoint used for determining OA Curve	25°F -3.9°C	Heat OA Hi	-10°F -23.3°C
	Heat Tank HP Hi	High heat tank setpoint for the OA Curve, Heatpump source	120°F 48.9°C	140°F 60°C	Heat Tank Lo
	Heat Tank B Hi	High heat tank setpoint for the OA Curve, Boiler source	160°F 71.1°C	180°F 82.2°C	Heat Tank Lo
	Heat Tank Lo	Low heat tank setpoint for the OA Curve	95°F 35°C	140°F 60°C	86°F 30°C
	Heat Diff Hi	Upper limit of the target heat band above setpoint	2°	20°	0°
	Heat Diff Lo	Lower limit of the target heat band below setpoint	5°	20°	0°
	Cool OA Hi	High OA cool setpoint used for determining OA Curve	90°F 32.2°C	110°F 43.3°C	Cool OA Lo
	Cool OA Lo	Low OA cool setpoint used for determining OA Curve	70°F 21.1°C	Cool OA Hi	60°F 15.6°C
	Cool Tank Hi	High cool tank setpoint for the OA Curve	55°F 12.8°C	70°F 21.1°C	45°F 7.2°C
	Cool Tank Lo	Low cool tank setpoint for the OA Curve	45°F 7.2°C	Cool Tank Hi	45°F 7.2°C

Section	Name	Description	Default Value	Max Value	Min Value
	Cool Diff	After reaching the SP the system will allow the temperature to rise by this value before cooling begins again	6°F -14.4°C	20°F -6.7°C	0°F -17.8°C
Thin Wall	Zone 1-5 Enables	Enables Thin Wall control for each zone	Disabled	N/A	N/A
	TW Setpoint	OAT setting that determines if the system will be heating or cooling when a Thin Wall enabled zone calls	50°F 10°C	100°F 37.8°C	0°F -17.8°C
	TW +/-	Hysteresis setting. System will not switch heating/cooling modes until an OAT of SP+/- is reached	5°F -15°C	10°F -12.2°C	1°F -17.2°C
	TW Timer	Timer for preventing the system from potentially getting stuck in one mode based on TW calls and OAT	15min	30min	1min (0min to disable timer)
Modbus	Address	Address index for the heatpump unit	1	20	1
	Model Type	Unit type to match the address setting. Choose from list of compatible units.	N/A	N/A	N/A
	Heat SP	Heating setpoint for the connected unit.	Initial values are read from the unit	Max and min temperature settings are determined by the max and min settings in the unit	
	Cool SP	Cooling setpoint for the connected unit.	Initial values are read from the unit	Max and min temperature settings are determined by the max and min settings in the unit	
Timers	Add Timer	Timer used for staging with Modbus connected units.	5min	90min	1min
	Shed Timer	Timer used for staging with Modbus connected units.	1min	90min	1min
System Settings	Pump Enable	Enables/disables the system pump output	Disabled	N/A	N/A
	Heat Enable	Enables/disables the heat output	Enabled	N/A	N/A
	Cool Enable	Enables/disables the cool output	Enabled	N/A	N/A
	Call Block	Enables/Disables off season calls	Disabled	N/A	N/A
Temperature Units	Temp Units	Switch between F and C	F	N/A	N/A

Condition	Possible cause	Solution
Heatpump, Boiler or Pump does not respond to call for conditioning.	Disconnected or broken wire.	Physically inspect the condition of the wires between the thermostat, air handler and the interface module, and between the interface module and the heatpump, boiler, or pump.
Heatpump gives a call for cooling when called upon for heating, or heating when called upon for cooling.	Reversing Valve Mode is set to the wrong mode.	Check the Heatpump RV and make sure it is set to the right mode Cooling (O) or Heating (B).
Unit is not working correctly	Settings or wiring could have been installed incorrectly.	Review all system settings and make sure module is wired properly.
Sensor error is showing on the LCD	Sensor input is either shorted or open.	Check sensor wiring and connections
N/A is showing for a temperature	Sensor input is either shorted or open but the sensor is not required for the current mode.	Check wiring if the sensor is supposed to be connected, or disregard otherwise.



IN UNITED STATES: 260 NORTH ELM ST. WESTFIELD, MA 01085 800-465-8558

IN CANADA: 7555 TRANMERE DRIVE, MISSISSAUGA, ONTARIO, L5S 1LR (905) 670-5888