



FLUSH MOUNT INSTALLATION DETAILS



Floor/Flush mounted outlets are 5" diameter they fit snugly in a hole drilled with a 5" hole saw.

Flush mount installation details apply to all Louvered Flush parts.

Floor outlets should not be placed in areas that will receive foot traffic. Simply drill a 5" hole with a piloted hole saw through the hardwood flooring only, leave the subfloor intact. Using the pilot hole left by the 5" hole saw drill a 3-1/2" or 4" hole through the subfloor.

Pull the sound attenuation tube up through the hole and twist the outlet onto the Kwik Connect, run around the connection with duct tape.

Your duct connection is now made and is leak free using SpacePak's ingenious connection system.

Material	Style	Order Code
Red Oak	Louvered Flush	45AC-TRM-ROLF
Black Cherry	Louvered Flush	45AC-TRM-BCLF
Hard Maple	Louvered Flush	45AC-TRM-HMLF
Black Walnut	Louvered Flush	45AC-TRM-BWLF
Southern Yellow Pine	Louvered Flush	45AC-TRM-SYLF
White Pine	Louvered Flush	45AC-TRM-WPLF
Douglas Fir	Louvered Flush	45AC-TRM-DFLF

