SECTION 22 34 36.29 - SAMPLE SPECIFICATION FOR RBI FUTERA II WATER HEATER

PART 1 - GENERAL

1.1 RELATED DOCUMENTS

A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 1 Specification Sections, apply to this Section.

1.2 SUMMARY

- A. This Section includes gas-fired, finned copper water tube water heaters for heating hot water.
- B. Related Sections include the following:
 - 1. Division 22 Section "Breechings, Chimneys, and Stacks" for connections to breechings, chimneys, and stacks.
 - 2. Division 22 Section "Feedwater Equipment" for connections to condensate and feedwater system.
 - 3. Division 22 Sections for control wiring for automatic temperature control.

1.3 SUBMITTALS

- A. Product Data: Include rated capacities; shipping, installed, and operating weights; furnished specialties; and accessories for each model indicated.
- B. Shop Drawings: Detail equipment assemblies and indicate dimensions, required clearances, method of field assembly, components, and location and size of each field connection.
 - 1. Wiring Diagrams: Detail wiring for power, signal, and control systems and differentiate between manufacturer installed and field installed wiring.
- C. Source Quality Control Tests and Inspection Reports: Indicate and interpret test results for compliance with performance requirements before shipping.
- D. Field Test Reports: Indicate and interpret test results for compliance with performance requirements.
- E. Maintenance Data: Include in the maintenance manuals specified in Division 1. Include parts list, maintenance guide, and wiring diagrams for each water heater.

1.4 QUALITY ASSURANCE

- A. Listing and Labeling: Provide electrically operated components specified in this Section that are listed and labeled.
 - 1. The Terms "Listed" and "Labeled": As defined in NFPA 70, Article 100.
 - 2. Listing and Labeling Agency Qualifications: A "Nationally Recognized Testing Laboratory" as defined in OSHA Regulation 1910.7.
- B. ASME Compliance: Water heaters shall bear ASME "H" stamp and be National Board listed, "HLW" where required.

- C. CSD-1 Compliance: Control devices and control sequences according to requirements of CSD-1.
- D. FM Compliance: Control devices and control sequences according to requirements of FM.
- E. IRI Compliance: Control devices and control sequences according to requirements of IRI.
- F. Comply with NFPA 70 for electrical components and installation.

1.5 COORDINATION

A. Coordinate size and location of concrete bases. Concrete, reinforcement, and formwork requirements are specified in Division 3 Section "Cast-in-Place Concrete."

1.6 WARRANTY

- A. General Warranty: The special warranty specified in this Article shall not deprive the Owner of other rights the Owner may have under other provisions of the Contract Documents and shall be in addition to, and run concurrent with, other warranties made by the Contractor under requirements of the Contract Documents. Installing contractor shall provide one year of warranty parts and labor.
- B. Special Warranty: Submit a written warranty, executed by the contractor for the heat exchanger.
 - Warranty Period: Manufacturer's standard, but not less than 5 years from date of Substantial Completion on the heat exchanger. Warranty shall be non-prorated and not limited to thermal shock. Additional 21 year thermal shock warranty on heat exchanger.

PART 2 - PRODUCTS

2.1 MANUFACTURER

- A. Available Manufacturers: Manufacturer shall be a company specializing in manufacturing the products specified in this section with minimum five (5) years experience. Subject to compliance with requirements, manufacturers offering water heaters that may be incorporated into the Work include, but are not limited to, the following:
- B. Design: Water heaters shall be CSA design certified and shall not release any condensate during operation. Water heaters shall be designed for operation with natural or propane gas and have a CSA certified input rating as noted on the drawings, and a thermal efficiency rating up to 83.4%.
- C. Service Access: The water heaters shall be provided with access covers for easily accessing all serviceable components. The water heaters shall not be manufactured with large enclosures, which are difficult to remove and reinstall. All accesses must seal completely as not to disrupt the sealed combustion process. All gas train components and blower motor must be accessible and able to adjust without the removal of covers or cabinet components.
- D. Indicating Lights: Each water heater shall include a diagnostic control panel indicating power on, operator, high limit, low water, low air, trial for ignition, main burner, flame failure, and inlet/outlet temperatures incorporated into the water heater. Access to the controls shall be through a control access door leaving diagnostic panel intact and not disrupted.

- E. Manufacturers: RBI (a Mestek Company) is the basis of design. Listed acceptable manufacturers shall be subject to compliance with requirements. Provide water heaters by one of the following:
 - 1. RBI (a Mestek Company)- Futera II Series
 - 2. Patterson-Kelley Co. Thermific
 - 3. Lochinvar Corp.- Power Fin Series Only (note the Lochinvar must be reduced to 85% efficiency in order to eliminate condensation. Lochinvar shall require the use of AL29-4C stack material.)
 - 4. Thermal Solutions- (Evolution) (note the thermal solutions will not meet the 5 year requirement 2.1:A and shall also condense if fired to 88% efficiency. Thermal Solutions shall require the use of AL29-4C stack material.)

2.2 COMPONENTS

- A. Combustion Chamber: The combustion chamber shall be constructed of stainless steel. An access door shall be provided for ease of service and inspection of the heat exchanger. Chamber shall be air-cooled and not require additional insulation.
- B. Heat Exchanger: The heat exchanger shall be inspected and bear the A.S.M.E. Section IV seal of approval. The heat exchanger shall be a four pass heat exchanger with a maximum working pressure of 160 psi. The heat exchanger's vertical design shall provide equal amounts of heat transfer throughout the entire heating surface. Each heat exchanger shall have copper tubes, with an integral copper finned tube of 7/8" I.D., .064" minimum wall thickness, 7 fins per inch, with a fin height of 3/8". Each end of the water tubes shall be strength rolled into the header. The heat exchanger shall be gasketless. Each individual tube can be re-tubed without the disturbance of the surrounding tubes. A pressure relief valve of 125 lb/sq. in. shall be equipped with the water heater and factory mounted. The headers shall be of bronze construction only, cast iron shall not be acceptable.
- C. Jacket: 18 gauge galvanized steel with Galvalume finish to protect the primary steel from oxidation. (Indoor/Outdoor rated).
- D. Gas Burner: The burner shall be constructed of low alloy steel and nickel-plated. The burner flame shall burn vertically and be of the power type with a forced draft fan. Burner shall fire to produce a full 360-degree flame pattern to provide equal distribution of heat throughout the entire heat exchanger. The burner shall be easily removed for maintenance without the disruption of any other major component of the water heater. A window view port shall be provided for visual inspection of the flame during firing.
- E. Ignition Components: Turbo Pilot™ proven spark to pilot ignition system hardware shall consist of an Alumina ceramic insulated ignition electrodes and UV sensing tube permanently arranged to ensure proper ignition electrode and UV alignment. Electrodes must be capable of removal while leaving the burner intact. Hot surface ignition systems of any type *will not* be accepted. Turbo Pilot™ will produce a stable and robust fire of 6,000 BTU's and will operate at minimum gas pressures of 1.5" W.C. and maximum pressures of 5.5" W.C. The Gas Regulating valve supplied with the pilot has a full adjustment within these parameters.
- F. Rated Capacity: The water heater shall be capable of operating at rated capacity with pressures as low as 6" W.C. at the inlet to the burner pressure regulator.
- G. The burner shall be capable of 85% efficiency without exceeding a NOx reading above 10ppm.
- H. The burner and gas train shall be provided with the following trim and features:

- 1. Burner Firing: On/off
- 2. Burner Firing: 2 Stage (1250-1950)
- 3. Burner Ignition: Intermittent spark
- 4. Safety Controls: Energize ignition, limit time for establishing flame, prevent opening of gas valve until pilot flame is proven, stop gas flow on ignition failure, and allow gas valve to open.
- 5. Flue Gas Collector: Enclosed combustion chamber with integral combustion air blower and single venting connection.
- 6. Gas Train: Manual gas valves (2), redundant main gas valves (solenoid/diaphragm, motorized), firing valve, 'B' valve, pilot gas pressure regulator, and automatic pilot gas valve. All components to be factory mounted.
- 7. Safety Devices: Optional high/low gas pressure switches, air flow switch, and blocked flue detection switch. All safeties to be factory mounted.

2.3 WATER HEATER TRIM

- A. Safety Relief Valve: ASME rated, factory set to protect water heater and piping as per schedule/ drawings.
- B. Gauge: Combination water pressure and temperature shipped loose for field installation. Inlet/ Outlet temperature gauges to be an integral part of the front water heater control panel to allow for consistent easy monitoring of temperatures factory mounted and wired.
- C. Flow Switch: Prevent burner operation when water falls below a safe level or when water flow is low. Flow switch shall be factory mounted. Provision for installation of a low water cut off shall be provided.
- D. Operating Controls: Water heaters shall be provided with a Honeywell RM7800 series digital flame safeguard. The flame safeguard shall be capable of prepurge cycles.
- E. Operating Temperature Control: Shall be a manual probe type controller adjustable from 120°F to 240°F, 49°C to 116°C. Control shall be factory mounted and sense the inlet temperature of the water heater through a dry well.
- F. High Limit: Temperature control with manual reset limits boiler water temperature in series with the operating control. High limit shall be factory mounted and sense the outlet temperature of the water heater through a dry well.

G. PROVIDE THE FOLLOWING STANDARD TRIM:

- 1. Bronze headers
- 2. Low air pressure switch
- 3. Blocked flue detection switch
- 4. Flow switch (factory mounted and wired)
- 5. Operating aquastat
- 6. Manual reset high limit
- 7. Air inlet filter

- 8. Inlet/outlet thermometers (factory mounted and wired)
- 9. FM gas train

H. PROVIDE THE FOLLOWING JOB SPECIFIC TRIM AND FEATURES:

- 1. All bronze circulator provided by the manufacturer (shipped loose)
- 2. Air inlet hood for exterior termination of air intake pipe (shipped loose)
- 3. Vent termination hood for exterior termination of vent pipe (shipped loose)
- 4. FM or IRI controls and gas train
- 5. Cupro-nickel heat exchanger
- 6. Probe type low water cut off, manual reset (shipped loose)
- 7. Diagnostic keyboard display for RM7800 series control
- 8. CSD-1 controls
- 9. Temperature/pressure gauge
- 10. Barometric damper
- 11. Motorized gas valves
- 12. Outdoor installation

2.4 MOTORS

- A. Refer to Division 22 Section "Motors" for factory installed motors.
- B. Water Heater Blower Motor: Open drip-proof motors where satisfactorily housed or remotely located during operation. Blower motor shall be externally mounted for ease of service. There shall be no requirement to remove covers or gas train components to remove the blower motor. Blower motor shall *not* exceed 3/4 HP and *not* require more than 12 amps.

2.5 SOURCE QUALITY CONTROL

A. Test and inspect water heaters according to the ASME Boiler and Pressure Vessel Code, Section IV. Water heaters shall be test fired in the factory with a report attached permanently to the exterior cabinet of the water heater for field reference.

PART 3 - EXECUTION

3.1 EXAMINATION

A. Examine area to receive water heater for compliance with requirements for installation tolerances and other conditions affecting water heater performance. Do not proceed with installation until unsatisfactory conditions have been corrected.

3.2 INSTALLATION

- A. Install water heaters level and plumb, according to manufacturer's written instructions and referenced standards.
- B. Install gas fired water heaters according to NFPA 54.
- C. Support water heaters on 4" (100 mm) thick concrete base, 4" (100 mm) larger on each side than base of unit.
- D. Install electrical devices furnished with water heater, but not specified to be factory mounted.
- E. Install a 1" drain valve on the outlet piping prior to the first shut off valve.

3.3 CONNECTIONS

- A. Connect gas piping full size to water heater gas train inlet with union.
- B. Connect hot water piping to supply and return water heater tappings with shutoff valve and union or flange at each connection.
- C. Install piping from safety relief valves to nearest floor drain.
- D. Connect breeching to water heater outlet, full size of outlet. The water heater shall operate on negative stack pressure and Category I vent material according to ANSI standards (AGA) (standard vertical venting). The water heater shall operate on positive stack pressure and Category III vent material. A listed stainless steel vent must be used. (Through the wall horizontal venting)
- E. Electrical: Comply with applicable requirements in Division 26 Sections.
- F. Ground equipment.
 - Tighten electrical connectors and terminals according to manufacturer's published torquetightening values. If manufacturer's torque values are not indicated, use those specified in UL 486A and UL 486B.

3.4 FIELD QUALITY CONTROL

- A. Manufacturer's Field Service: Engage a factory authorized service representative to supervise the field assembly of components and installation of water heaters, including piping and electrical connections. Report results in writing.
 - 1. Test and adjust controls and safeties. Replace damaged and malfunctioning controls and equipment.
- B. Manufacturer's representative shall supply a factory authorized service technician to start up the water heaters.

3.5 CLEANING

- A. Flush and clean water heaters on completion of installation, according to manufacturer's written instructions.
- B. After completing water heater installation, including outlet fittings and devices, inspect exposed finish. Remove burrs, dirt, and construction debris and repair damaged finishes including chips, scratches, and abrasions with manufacturer's touchup paint.

3.6 COMMISSIONING

- A. Engage a factory authorized service representative to provide startup service. Start up to be performed only after complete boiler room operation is field verified to offer a substantial load, and complete system circulation. One year warranty shall be handled by factory authorized tech.
- B. Verify that installation is as indicated and specified.
 - Verify that electrical wiring installation complies with manufacturer's submittal and installation requirements in Division 26 Sections. Do not proceed with water heater startup until wiring installation is acceptable to equipment Installer.
- C. Complete manufacturer's installation and startup checklist and verify the following:
 - 1. Water heater is level on concrete base.
 - 2. Flue and chimney are installed without visible damage.
 - 3. No damage is visible to water heater jacket, refractory, or combustion chamber.
 - Pressure reducing valves are checked for correct operation and specified relief pressure.
 Adjust as required.
 - 5. Clearances have been provided and piping is flanged for easy removal and servicing.
 - 6. Heating circuit pipes have been connected to correct ports.
 - 7. Labels are clearly visible.
 - 8. Water heater, burner, and flue are clean and free of construction debris.
 - 9. Pressure and temperature gauges are installed.
 - 10. Control installations are completed.
- D. Ensure pumps operate properly.
- E. Check operation of pressure reducing valve on gas train, including venting.
- F. Check that fluid level, flow switch, and high temperature interlocks are in place.
- G. Start pumps and water heaters, and adjust burners to maximum operating efficiency.
 - 1. Fill out startup checklist and attach copy with Contractor Startup Report.
 - Check and record performance of factory provided water heater protection devices and firing sequences.
 - 3. Check and record performance of water heater fluid level, flow switch, and high temperature interlocks.
 - 4. Run-in water heaters as recommended or required by manufacturer.

- H. Perform the following tests for each firing rate for high/low burner. Adjust boiler combustion efficiency at each firing rate. Measure and record the following:
 - 1. Inlet gas pressure.
 - 2. Gas pressure on manifold.
 - 3. Flue gas temperature at boiler discharge.
 - 4. Flue gas carbon dioxide and oxygen concentration.
 - 5. Natural flue draft.
- I. Measure and record temperature rise through each water heater.

3.7 DEMONSTRATION

- A. Engage a factory authorized service representative to train Owner's maintenance personnel as specified below:
 - Operate water heater, including accessories and controls, to demonstrate compliance with requirements.
 - 2. Train Owner's maintenance personnel on procedures and schedules related to startup and shutdown, troubleshooting, servicing, and preventive maintenance.
 - 3. Review data in the maintenance manuals. Refer to Division 1 Section "Contract Closeout."
 - 4. Review data in the maintenance manuals. Refer to Division 1 Section "Operation and Maintenance Data."
 - 5. Schedule training with Owner with at least 7 days advance notice.

END OF SECTION 22 34 36.29