

# **RBI Futera III/Fusion/XLF, Flexcore, Torus, and Encore HeatNet V3 LonWorks Configuration Revision History**

---

## **Version 2.00 – 06/15/2023**

- 1) Fixed cycles so that boilers 9-16 are updated and available.
- 2) Fixed runtime so that boilers 9-16 are updated and available.
- 3) Renamed nvoSpare1 to nvoDHWTemp.
- 4) Renamed nvoSpare2 to nvoStackTemp.
- 5) Renamed nvoBTUH to nvoSystemBTUH.
- 6) Added nvoAddBlrTimer (Master Only).
- 7) Added nvoShedBlrTimer (Master Only).

## **Version 1.20 – 10/3/2019**

Added Local Flow sensor Input Register

## **Version 1.11 (3/7/2017)**

Fixed an issue with reading/writing negative values for nviOARLoAirTemp.

## **Version 1.10 (7/8/2014)**

- 1) Added nvoBTUH (SNVT\_btu\_f).
- 2) Added nvoSysReturnTemp (SNVT\_temp\_p).
- 3) Added nvoSystemFlow (SNVT\_flow\_f).
- 4) Added nvoHeatingBlrsOn (SNVT\_count).
- 5) Added nvoDHWBlrsOn (SNVT\_count).
- 6) Added nvoManualBlrsOn (SNVT\_count).
- 7) Added Stack Sensor not detected to BoilerStatus4 flags.
- 8) Added System Return Sensor not detected to BoilerStatus4 flags.

## **Version 1.00**

Initial Release