

# **RBI Futera III/Fusion/XLF, Flexcore, Torus, and Encore HeatNet V3 Metasys® N2 Configuration Revision History**

---

## **Version 2.00 – 06/15/2023**

- 1) Fixed cycles so that boilers 9-16 are updated and available.
- 2) Fixed runtime so that boilers 9-16 are updated and available.
- 3) Renamed Spare1 to DHWTemp.
- 4) Renamed Spare2 StackTemp.
- 5) Renamed BTUH to SystemBTUH.
- 6) Added AddBoilerTimer (Master Only)
- 7) Added ShedBoilerTimer (Master Only)

## **Version 1.10 – 10/3/2019**

- 8) Added Local Flow sensor Input Register

## **Version 1.02 (3/7/2017)**

Fixed an issue with reading/writing negative values for OARLowAirTemp.

## **Version 1.01 (11/5/2014)**

- 1) Fixed an issue that prevented reading many of the status bits for boilers 9 – 16.

## **Version 1.00 (9/4/2014)**

- 1) Added BMSFlowRateGPM to Boiler1 (Master).
- 2) Added BMSLimitBoilers to Boiler1 (Master).
- 3) Added AvailableBoilers to Boiler1 (Master).
- 4) Added SystemBTUH to Boiler1 (Master).
- 5) Added SystemReturnTemp to Boiler1 (Master).
- 6) Added SystemFlow to Boiler1 (Master).
- 7) Added HeatingBoilersOn to Boiler1 (Master).
- 8) Added DHWBoilersOn to Boiler1 (Master).
- 9) Added ManualBoilersOn to Boiler1 (Master).
- 10) Added BoilersFlowLimited to Boiler1 (Master).
- 11) Added BoilersBMSLimited to Boiler1 (Master).
- 12) Added StackSensorNA to all boilers.
- 13) Added SysReturnSensorNA to all boilers.