

# **S28 Metasys® N2 Configuration**

## **Revision History**

---

### **Version 1.22 (3/7/2017)**

- 1) Added Stack Temperature
- 2) Fixed an issue with reading/writing negative values for OARLowAirTemp.

### **Version 1.21 (11/05/2014)**

Fixed an issue that prevented reading many of the status bits for boilers 9 – 16.

### **Version 1.20 (9/3/2014)**

- 1) Added Boiler###\_LocalOverride. Updated Objects Documentation.
- 2) Changed Boiler##\_ValveAlarm to Boiler##\_IRIAlarm to be consistent with other documentation. Updated Objects Documentation.
- 3) Changed Boiler##\_Blower to Boiler##\_BlowerOn to more accurately indicate its' function. Updated Objects Documentation.
- 4) Renamed Boiler##\_Damper to Boiler##\_DamperProve1. Updated Objects Documentation.
- 5) Renamed Boiler##\_DamperProve to Boiler##\_DamperProve2. Updated Objects Documentation.